

INSTALLATION INSTRUCTIONS

MODEL 800 ADV AND 800C ADV



This installation manual provides the trained door technician information required to install, troubleshoot and maintain an Advanced Performance Service Door.

READ COMPLETE INSTRUCTIONS BEFORE INSTALLING DOOR.

Some installation tasks listed in this document are found in other documents.

**Please refer to the appropriate document(s) as directed;
308577 Hilti Kwik Bolt Installation
Found on odcexchange.com**

Installation, repairs, and adjustments must be made by a trained door system technician using proper tools and instructions.

INSTALLER: Leave this manual with the end user!

Product may be covered by one or more patents. See www.wayne-dalton.com/patents for details.

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE
1	SAFETY INFORMATION	3-4
2	HOW TO USE THIS MANUAL	5
3	GENERAL INFORMATION	6-8
	COMPONENT IDENTIFICATION DRAWING	6
	INSTALLATION DATA SHEET	8
4	INSTALLATION	9-23
5	WIRING	24-34
	CONTROL PANEL WIRING	25-28
	JUNCTION BOX WIRING	29
	PHOTOEYE WIRING	30-31
	ENCODER WIRING	32
	OPTIONS WIRING	33-34
6	INITIAL STARTUP PROCEDURE	35-44
7	TROUBLESHOOTING	45-50
8	SERVICE AND MAINTENANCE	51
9	ILLUSTRATED PARTS BREAKDOWN	52-53
END	WARRANTY	54

SECTION 1 - SAFETY INFORMATION

OVERVIEW OF POTENTIAL HAZARDS READ THIS SAFETY INFORMATION

⚠ WARNING

Advanced Performance service doors are large, heavy objects that move with the help of electric motors. Since moving objects and electric motors can cause injuries, your safety and the safety of others depends on you reading the information in this manual. If you have any questions or do not understand the information presented, you should consult a licensed professional.

In this section and those that follow, the words "**DANGER**", "**WARNING**", and "**CAUTION**" are used to stress important safety information. The word:

⚠ DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION indicates a potentially hazardous situation which, if not avoided, may result in injury or property damage.

The word **NOTE** is used to indicate important steps to be followed or important considerations.

1. Read manual and warnings carefully.
2. Keep the door in good working condition.
3. This door is equipped with a sensing edge, check sensing edge operations daily. Make any necessary repairs to keep it functional.
4. All models are equipped with an overcurrent device. This must be manually reset following an overcurrent condition.
5. Keep instructions in a prominent location near the Control Panel.

POTENTIAL HAZARD	EFFECT	PREVENTION
 <p>MOVING DOOR</p>	<p>⚠ WARNING Can Cause Serious Injury or Death</p>	<p>Do NOT operate unless the doorway is in sight and free of obstructions. Keep people clear of opening while door is moving.</p> <p>Do NOT change control to momentary contact unless an external reversing means is installed.</p> <p>Do NOT operate a door that jams.</p>
 <p>ELECTRICAL SHOCK</p>	<p>⚠ WARNING Can Cause Serious Injury or Death</p>	<p>Turn OFF electrical power before removing Control Panel or motor cover.</p> <p>When replacing Control Panel cover make sure wires are NOT pinched or near moving parts.</p> <p>Operator must be electrically grounded.</p>

SECTION 1 - SAFETY INFORMATION

Safety Instructions

Electrical Power Requirements for all Advanced Performance Service Door Models

All Advanced Performance Service Door models are available in 220/240V AC 1-phase or 230V AC and 460V AC 3-phase as input voltage options. 575V AC 3-phase input power is available with the use of a 575V AC/460V AC step-down transformer for all Advanced Performance Service Door models. **YOUR LOCAL CODES MAY REQUIRE THAT THE INCOMING POWER TO YOUR ADVANCED PERFORMANCE SERVICE DOOR HAVE A LOCK-OUT / TAG-OUT EQUIPPED FUSED DISCONNECT SWITCH (TO BE FURNISHED BY OTHERS) WITHIN EYESIGHT OF THE DOOR'S CONTROL PANEL.** Incoming power wiring must meet all NEC and local building codes, plus be properly sized for the control panel's amperage rating on the nameplate. To reduce the risk of electric shock, the chassis of the control panel must be properly grounded.

CAUTION

Advanced Performance Service Door Models must be supplied by a properly grounded voltage supply, e.g. 220/240 VAC 1-phase or 208/230/460/575 VAC 3-phase. Floating (Open Delta) ungrounded voltage supply sources should not be used. For 480 VAC, 240 VAC or 120 VAC unbalanced Delta systems should **NOT** be used. Voltage unbalance is a common occurrence on Delta supply systems, which power both single phase and three phase loads, which can lead to unequal voltages on each phase leg. Voltage unbalance can cause deterioration of motor performance, such as loss of torque, overheating, decreases in the winding insulation life, and can cause motor starter contacts on the control panel to permanently "weld" closed. Voltage unbalance can be caused by inadequate conductor sizing, Delta transformer sizing, excessive single-phase loads, poor grounding, or intermittent high resistance faults which may cause destructive over-voltages to occur.

Wayne Dalton's warranty will not cover damage caused by failure of the motor, control panel or other electrical components due to the use of an inadequately grounded system.

Section 2 - How to Use This Manual

- **Section 1 - Safety Information**

Safety Information and Instructions. Important information related to safety terminology used throughout this manual. Safety related instructions must be followed at all times while performing any steps/tasks/instructions detailed in this manual.

- **Section 2 - How to Use This Manual**

Provides an overview of component information and how to use this manual.

- **Section 3 - General Information**

Details pre-installation issues that are recommended to be considered and/or resolved prior to beginning this door system installation.

The sections of this Installation Manual provide the information required to install, troubleshoot and maintain the *Models 800 ADV and 800C ADV Advanced Performance Service Door Systems.*

WARNING

Failure to correctly perform all steps in Sections 4–6 can result in serious injury or death. Each section must be followed in step by step order to complete a successful installation.

- **Section 4 - Installation**

Provides step by step physical installation instructions for this product.

- **Section 5 - Wiring**

Provides step by step wiring instructions for this product.

- **Section 6 - Door System Set Up Procedures**

Provides step by step control set up and programming instructions for this product.

- **Section 7 - Troubleshooting**

Details important troubleshooting information for typical installation, operator fault codes for troubleshooting and service, and normal operation codes that may occur.

- **Section 8 - Service and Maintenance**

Provides related information on service and maintenance items.

- **Section 9 - Illustrated Parts Breakdown**

Provides an illustrated parts breakdown for this product, including parts identification.

- **Warranty**

Section 3 - General Information

Component Identification Drawing

NOTE: COMPONENTS AND COMPONENT LOCATIONS ARE SHOWN FOR REFERENCE ONLY. YOUR UNIT INSTALLATION AND COMPONENT LOCATIONS MAY BE DIFFERENT.




Fig 2-A

Section 3 - General Information

Job Site Issues/Considerations

The following list of items should be considered prior to installing an Advanced Performance Door.

- Verify the opening measurements, head room, and side room required for this installation.
- Type of door jamb.
- Availability of a power supply, which side of door it is on and what the line voltage is.
- Door system mounting environment. Items to consider include operator location, dampness of location, dustiness of the location and corrosiveness of the location.
- Door activation needs and requirements. Examples include 3 button control stations, 1 button control stations, radio controls, pull cords, loop detectors, photoeyes, key switches, motion detectors, etc.
- Accessory equipment needs and requirements. Examples include sirens, warning lights, etc.

Entrapment Protection

Photoeyes and sensing edges are required for all electrically operated Advanced Performance doors. Both photoeyes and sensing edge are standard with these models. Do **NOT** disable them.



Door Specifications

DOOR MODEL NUMBER (circle one):	800 ADV / 800C ADV
OPENING WIDTH:	
OPENING HEIGHT:	
MOTOR MOUNTING:	<input type="checkbox"/> INTERIOR or <input type="checkbox"/> EXTERIOR (check one) <input type="checkbox"/> LEFT HAND or <input type="checkbox"/> RIGHT HAND
CURTAIN COLOR:	
OPERATOR:	HP _____ RATIO _____
OPERATOR VOLTAGE:	
"C" DIMENSION	_____ "G" DIMENSION _____
HEADROOM REQUIREMENT:	
SIDE ROOM:	DRIVE _____ NON-DRIVE: _____
GUIDE GAP	_____ GUIDE TYPE _____
CURTAIN WEIGHT:	_____

Installation Data

NAME PLATE SERIAL NUMBER:
JOB NAME:
DISTRIBUTOR:

NOTE: The ID plate is located on the bottom bar.

Section 3 - General Information

SHOP DRAWING





1 SHOP DRAWING

- A. Your shop drawing should be found inside the door hardware bag. You will need to refer to the data on this drawing during installation. Record the pertinent data on page 7 of this manual as a backup.
- B. Verify that the "Factory Order Number" on the door components matches the one shown on the shop drawing.

2 PRE-INSTALLATION CHECK LIST

Ensure the door installation can be accomplished before proceeding.

- Check that the wall opening, **Fig. 3-B**, matches the Opening Width and Height shown on the shop drawing.
- Check that the sill is level and plumb.
- Verify the guides you received are suitable for the jambs. Compare the guide type on the shop drawing with **Fig. 3-C**.



NOTE: WIDTH [C] IS IMPORTANT AND MUST BE HELD

DOOR QTY.	ITEM NO.	HAND OF OPER.	CUST. OPG. NO.	WIDTHS			HEIGHTS			GUIDE		FOR BRACKET		SLAT LENGTH
				A	C	E	B	D	F	H	X	Y		
					X'-X''									

Wayne Dalton a Division of Overhead Door Corporation

Rolling Door Division

ADV ROLLING DOOR MODEL :

PROJECT :

ARCH :

G.C. :

DISTR :

DISTR P.O. NO. : PREPARED BY : DATE :

REVISION ORDER NO. DWG. NO.

XXXXXXXXXXXX OF

Section 4 - Installation

STEP 1 INSTALL GUIDE WALL ANGLES

NOTE: It is only necessary to disassemble the guides for screw attachment of "E" type guides. Welded "E" assemblies and all "Z" assemblies may be installed as assembled from the factory.

- A. Remove the middle angles and outside angles from the guide wall angles. (Perform this for "E" non-welded guides only.)
- B. Mount guide wall angles to achieve the "C" dimension (on the shop drawing) plus 1/2" as shown in the illustration on the previous page **Fig. 3-C**. (The extra 1/2" allows for the thickness of the outside angle.)
 - The "G" ("C" + 1/2") dimension must be held within 1/8" over the entire height of the wall angle.
 - The guides must be on a level plane and plumb.
 - Place shims under the wall angle on the tall side of the opening if necessary to put them on level, **Fig. 3-B**.
 - Check plumb with a level or plumb bob.

STEP 2 MOUNTING METHODS

The following instructions use the Z-Guide positioning for the wall angles, use the Z-Guide or E-Guide positioning best suited for your site.

Masonry Jamb

- Hold Z-Guide wall angle against the wall and drill mounting holes through the slots using drill size shown in **Table 4-A**. Install jamb fasteners (**Table 4-A**) on one wall angle. Install second wall angle at "G" distance, refer to **Fig. 3-C** on the previous page. Check for level and plumb. Use spacers between Guide and wall as needed for plumb.


Steel Jamb

Steel jamba (welded or screwed) use "E" guides, all others use "Z".

- SCREW ATTACHMENT OPTION
 - Hold E-Guide wall angle against the jamb and drill holes through the slots using drill size shown in **Table 4-A**. Install all jamb fasteners (**Table 4-A**) on one wall angle, then install second wall angle at "G" ("C" + 1/2") (**Fig. 3-C**) distance. Check for level and plumb.
- WELD ATTACHMENT OPTION
 - Hold E-Guide wall angle against the jamb and tack weld in place. Install second wall angle at "G" ("C" + 1/2") (**Fig. 3-C**) distance. Check for level and plumb. Apply welds as shown in **Fig. 4-B**, using welding electrodes E6010, E6011 or E7014.

JAMB	FASTENER	DRILL SIZE	JAMB FASTENER SPECIFICATIONS
Steel	1/2" self-tapping screw	27/64" diameter	Steel jamba must be minimum 3/16" thick
Concrete	1/2" wedge anchor	1/2" diameter	Drill hole at least 4" from jamb corner per OHD Installation Instruction 308577 available on odcexchange.com .
Filled block	1/2" wedge anchor	1/2" diameter	Drill hole at least 4" from jamb corner per OHD Installation Instruction 308577 available on odcexchange.com .
Wood	1/2" lag screw	3/8" diameter	Drill hole 3" deep
Unfilled block	1/2" thru bolt	9/16" diameter	Install 3" O.D. steel washer on opposite side of wall.

Table 4-A



NOTE: When the wall angle extends above the steel of the jamb or header, use washers, spacers or shims to fill the gap between the masonry portion of the wall and the wall angle. Use through bolts to fasten the wall angle in the area above steel, **Fig. 4-C**.

Section 4 - Installation

STEP 3 IDENTIFY HEADPLATE BRACKETS, Fig. 4-D

Right hand drive is shown (left hand drive opposite).

STEP 4 IDENTIFY DRIVE END OF BARREL ASSEMBLY, Fig. 4-E

Right hand drive is shown (left hand drive opposite). The **drive end** of barrel assembly typically is longer and is keyed. **Fig. 4-E**

STEP 5 ASSEMBLE BARREL AND HEADPLATE BRACKETS, Fig. 4-G

- Slide the drive headplate bracket and bearing onto drive end of the barrel shaft (longer shaft).
- Slide the non-drive headplate bracket and bearing onto the non-drive end of the barrel shaft (short shaft).
- Slide one set collar onto the drive end and another set collar onto the non-drive end of the barrel assembly.
- Lightly tighten the set screws on the set collars.
- The distance between the outside of the headplate brackets should be less than the "C" dimension, **Fig. 3-C Page 8**.
- Do **NOT** tighten bearing or set collar set screws at this time.




Fig 4-D




Fig 4-E





Fig 4-G



Section 4 - Installation

⚠ CAUTION

Use proper lifting equipment and correct lifting procedures to avoid injury.

STEP 7 MOUNT BRACKETS AND BARREL ASSEMBLY, Fig. 4-F

- A. Headplate brackets must be square to the wall and parallel.
- B. Use hex bolts, nuts and washers (provided) to fasten headplate brackets to the inside of the wall angles. Use washers under both the bolt head and nut.
- C. Bolt heads must be on the inside of the headplate brackets.
- D. Use a level to **make sure the barrel is level**.
- E. Position the barrel assembly such that the curtain, mounted on the barrel, will be centered between the headplates, **Fig. 4-H**.

⚠ CAUTION

A level barrel is crucial to the correct operation of the curtain. If the barrel is NOT level, the curtain will begin to “telescope” towards the low end and may damage the curtain.

- F. Tighten bracket bearing set screws on both headplates to prevent barrel from sliding side to side.
- G. Slide set collars against headplate bearings and tighten set screw on the set collars.




Fig 4-F



Fig 4-H

Section 4 - Installation




Fig 4-I

STEP 8 INSTALL MOTOR

- Remove motor mounting hardware from the motor bracket **FIG 4-I**.
- Loosen (but do not remove) the hardware holding the motor bracket to the headplate.
- Apply lubricant (anti-seize compound, provided) to inside of gearmotor bearing.
- Slide the motor onto the shaft and reinstall the mounting hardware. **FIG 4-I**
- Tighten the motor bracket hardware loosened in a previous step.
- Manually turn the shaft as needed to align the keyway of the motor with the keyway of the shaft. Install the key.
- Install the sprocket and set collar, as shown in **Fig. 4-I**.

⚠ WARNING

Do NOT connect power at this time. Power must be routed through the controller that will be mounted in a later step. Connecting Mains power directly to the motor will result in uncontrolled operation with possible serious injury or death.

Section 4 - Installation



STEP 9 INSTALL CURTAIN ONTO BARREL

NOTE: If guide angles are already installed, cover the bell mouth opening of the guide angles to protect the curtain from being scratched or damaged during these steps.

- A. Pull the red manual operation cord on the motor (**FIG 4-J(a)**) and use the hand chain to rotate the barrel assembly so that the bolt holes or studs on the barrel rings are facing up. Different barrel assembly lengths will have more or less rings/studs, **Fig. 4-K(a)** and **Fig. 4-K(b)** on page 14.
- B. Suspend the curtain below the barrel on two or three slings or ropes rated for the weight of the curtain, **Fig. 4-J(b)**. (Refer to your Shop drawing.)

⚠ WARNING

Ensure the slings/ropes are securely fastened as they will temporarily support the weight of the curtain. Improper use of slings /ropes could result in the unsecured curtain falling which could cause severe injury or death.



Section 4 - Installation

- C. Center the curtain between the headplate brackets and pull the top slat up and over the back side of the barrel.
- On small doors, the curtain can be rotated by hand.
 - On large doors attach the top slat to two slings/ropes and rotate the slings/ropes to bring the top slat into position.
- If the barrel has rings,
- Pull the curtain up and hold top slat against the rings, **Fig. 4-K(a)**.
 - Align the slots in the top slat with the holes in the rings.
 - Fasten the curtain to the rings with 3/8-16 x 5/8" Torx head screw and washers provided.

⚠ CAUTION



Take care to prevent stripping threads. Stripping could result in the need to replace the barrel rings.

If the barrel has studs,

- Pull the curtain up and hook the slots in the top slat over the studs.
 - Fasten at each stud with a 1/4-20 x 3/4" round head screw, flat washer, and two clamp washers (provided), **Fig. 4-K(b)**.
- D. Coil the curtain completely onto the barrel using the hand chain.
E. Remove bottom slat end lock and attach Sensing edge.
F. Replace bottom slat end lock.
G. Feed safety edge and curtain into bellmouth of guide.
H. Using the hand chain, lower curtain into guides.
I. Install provided bottom bar stops.

⚠ WARNING

Do NOT remove the slings or ropes at this time.



NOTE: In figures 4-K(a) & K(b) Headplate and bearing not shown for clarity.

Section 4 - Installation

NOTE: If you have welded "E" assemblies or "Z" assemblies factory assembled and have already installed them in a previous step, skip Step 10.


STEP 10 INSTALL GUIDE ANGLES

Bolt the middle angles and outer angles to the wall angles as shown in **Fig. 4-L**. (Wall angles may be mounted inside or outside based on installation requirements, **Fig. 4-M**.)

- The "Guide Gap" **MUST** be set to the value given on the Shop drawing. Refer also to Door Specifications on page 7.

STEP 11 RELEASE THE CURTAIN

- A. Pull the green motor cord to re-engage the motor and brake.
- B. Remove the slings or ropes. The curtain is now held in place by the motor brake.



Section 4 - Installation

STEP 12 LEVEL DOOR (IF NEEDED)

- If during previous step the door rolled up level and straight, skip this step.
 - A.** Check that guides are plum, square, level, and are properly mounted onto floor and wall.
 - B.** Check that the pipe is level.
 - C.** Check that the attachment of the curtain is straight on the pipe.
- If all of the above is correct and the door still rolls up out of level, a shim may need to be added.

SHIM MATERIALS:

- A piece of rubber is the desired material for a shim.
- A piece of cardboard could be used but may deteriorate over time.
- Use a 1/8" x 6" x 6" thick piece of material and increase thickness or pieces depending on the result acquired.

APPLICATION OF SHIM:

- To determine the side in which the shim will be applied, the door will need to be in the open position.
 - When facing the door, the bottom bar will be unlevel. The lower side of the bottom bar will be the side in which the shim needs to be placed.
 - The hood may need to be loosened or removed for the application of the shim.
- To apply the shim, two laborers might be required.

INSTALLING THE SHIM:



- D.** Close the door fully.
- E.** When door is at bottom make sure door is in hand chain mode.
- F.** Turn off the power to the motor (if applicable) to ensure safe application of the shim.
- G.** Backwind the door using the chain. Lock chain in place using chain keeper.

WARNING

When the door is wound backwards there is a force in which the door will want to wind forward. Secure the door in this position by locking hand chain onto chain keeper to prevent injury.

- H.** As the curtain is wound backwards apply the shim to the lower side between the pipe and slats or on the ring of the low side.
- I.** Restore power to the motor (if applicable).
- J.** Check the level of the bottom bar while door is in the open position. If it is not level, add a second shim and check again.

NOTE: If the door has wind locks there may be some stacking interference in the wind locks as the door is wrapping during operation. This is a normal characteristic. For wind lock applications the doors bottom bar should be level at the open position.



Section 4 - Installation

⚠ DANGER

LINE POWER should **NOT** be installed at this time. In the following steps electrical components will be physically mounted. Ensure that all incoming power supplies have been de-energized prior to beginning work on attachment of electrical control systems. Use proper Lock Out/Tag Out procedures.



Do NOT connect components to electrical supply until directed to do so.

STEP 12 MOUNTING AND CONNECTING/WIRING STANDARD ELECTRICAL COMPONENTS

This step encompasses the installation and wiring of several components;

- Junction Box,
- Control Panel,
- Photoeye

- B.** Find a suitable and easily accessible location for the **Junction Box, Fig. 4-S(a)**.
- Locate Junction Box on the wall near the motor, but **OUTSIDE** the end cover. Verify component cables will reach before mounting Junction Box and that the end cover does not interfere with access to Junction Box.
 - Away from heat sources.
 - With no interference of moving parts of the door system.
 - Where cables can be well secured while preventing unnecessary strain.
 - Use the Junction Box exterior mounting fixtures to mount to wall. (Fasteners not provided.)
- C.** Find a suitable and easily accessible location for the **Control Panel, Fig. 4-S(b)**.
- Adjacent to the door, on the wall, about 5 feet above the floor at the center of the panel (roughly eye level). It may be mounted higher in retail applications to reduce tampering.
 - Where all moving parts of the door system are visible while at the control panel.
 - Away from heat sources.
 - With no interference of moving parts of the door system.
 - Where cables can be well secured while preventing unnecessary strain.
 - Mount the Control Panel to the wall. (Fasteners not provided.) Use supplied mounting tabs as necessary.



Section 4 - Installation


STEP 12 MOUNTING AND CONNECTING/WIRING STANDARD ELECTRICAL COMPONENTS (continued...)

D. Photoeye assemblies are factory mounted to their protective shields. Attach to guides as follows, **Fig. 4-S(c)**.

1. Mount Retroreflective photoeye or optional photoeye receiver (prewired cable) to the lowest guide assembly bolt (Drive / controller side) such that the Photoeye is aimed to the opposite guide. Route the cable up and plug into the junction box Position 4 labeled "Photoeye RX." See **Fig. 5-J** page 29.

2. Mount the photoeye reflector or optional photoeye transmitter to the lowest guide assembly bolt on the opposite guide directly across from the photoeye / receiver. (Optional thru beam only) Route the wire up the guide and over the header to the Junction box to connector position 3 labeled "Photoeye Tx". See **Fig. 5-J** page 29.

3. Photoeyes will be aligned later, when power is applied to the Control Panel. See pages 30-31 Photoeye Adjustment.



NOTE: Photoeyes are attached to their protective brackets at the factory and must be mounted to the guides using the hardware provided.

NOTE: For parking garage applications photoeyes may be mounted higher to prevent the beam from shooting beneath vehicles.

Section 4 - Installation

STEP 13 LOW VOLTAGE WIRING

A. Connections to the door are completed by attaching the two screw-in cables to the control panel's base, **Fig. 4-T**.

1. 5 pin cable connector

- Encoder

2. 12 pin cable connector

- Photoeye Receiver
- Photoeye Transmitter
- Sensing edge
- Optional Input 1
- Optional Input 2


3. Two options may be connected to the Junction Box by the installer. Additional options must be wired to the spare inputs on the Control panel. Use the corresponding option inputs.

- Radio Remote to the Junction Box connector 6 labeled "Option 2".
- Floor loop to the Junction Box connector 5 labeled "Option 1".
- Motion Detector to the Junction Box connector 5 labeled "Option 1".
- Wall mounted push button stations to the main Control Panel


Fig. 8-J on page 46.

Note: When installing push buttons, use the 24V supplied by the Control Unit as the common.


- TO JUNCTION BOX
1. SENSING EDGE (WHITE)
 2. INTERLOCK (GREEN)
 3. NOT USED
 4. PHOTOEYE RECEIVER (GRAY)
 5. OPTION 1 (PINK)
 6. OPTION 2 (RED)
 7. NOT USED
 8. NOT USED
 9. NOT USED
 10. COMMON (0V) (BLUE)
 11. POWER (24V) (BROWN)
 12. GND (GREEN/YELLOW)



- TO ENCODER
1. 12V (BROWN)
 2. A SIGNAL (WHITE)
 3. B SIGNAL (BLUE)
 4. 0V (BLACK)
 5. PULSE (GRAY)



FROM JUNCTION BOX



ENCODER CABLE

Fig 4-T

Section 4 - Installation

STEP 14 **14. MOTOR & POWER WIRING (HIGH VOLTAGE)** (These tasks are also diagrammed in **Fig. 5-D, 5-G & 5-H** on pages 24-26.)

- A.** Route **Motor Power Cable** (provided, factory wired to motor) through water-tight fitting in the **SECOND** hole from left side of Control Panel bottom.
1. Connect the lighter gauge, twisted pair wires to the blue colored **Motor Brake** terminals next to the disconnect switch. Either wire can connect to either terminal. It is labeled "B1" and "B2".
 2. Connect the green and yellow ground wire, the braided cable shield and the non-insulated ground wire together to the Green and Yellow terminal.
 3. Connect the thicker motor wires to Terminals T1, T2 and T3 on the green screw connectors on the bottom left of the control unit. The order doesn't matter since the motor rotation can be changed using the internal programming during Set-up in **Section 6**.

⚠ WARNING

Before beginning this phase of installation, ensure POWER SUPPLY is disconnected! A licensed electrician must perform the following step.

A licensed electrician must perform the following step.

- B.** Route **Main Power Cable** (not provided) through a water-tight fitting (not provided) in the **FIRST** hole from the left side of the Control Panel bottom.
- Connect 3-phase power lines to the disconnect. Connect the ground wire to the Ground Terminal to the left of the disconnect.




Fig 4-U

Section 4 - Installation

STEP 15 INSTALL SAFETY LABELS, Fig. 4-V

Product safety labels must be installed.

- A. Find Safety Labels in hardware box.
- B. Attach **Sensing edge** Safety Label to the bottom bar.
- C. Place remaining Safety Label at a readable height on door drive side guide or jamb.

NOTE: Product safety labels should be periodically inspected and cleaned by the product user as necessary to maintain good legibility. Order replacement safety labels from the door manufacturer as required to maintain legibility.

STEP 16 PRE-HOOD CHECK LIST

- A. Operate the door manually several times. Make sure the endlocks or windlocks are not rubbing endplates through the entire travel of door.
- B. Check that the bottom bar is level at top and bottom and the curtain is not binding against the back of the guides.
 - If curtain is level at bottom but not at top, place shims between the curtain and barrel on the low side.
- C. Verify good mechanical connection and tightness of fasteners, i.e., guides, headplates, set screws.
- D. Position the door at the half open position.

NOTE: Hood and Brush Seal installation can be delayed until the last step to allow easy access to curtain during wiring set-up and final adjustments.




Fig 4-V

Section 4 - Installation

STEP 17 INSTALL HOOD

- A. Pre-drill the hood flange at 18" spacing for wall mounting screws. Hole diameter is dependant on the size of the wall fasteners (not provided) used to attach hood to wall.
- B. Place the hood over the hood bands or straps on the headplates (and, if provided, hood supports) and **against** the wall, **Fig. 4-W**.
- C. Fasten the hood to the hood bands or straps.
–At top, bottom and middle of the bands, drill 3/16" diameter holes through the hood and hood bands or straps on the headplates. Fasten the hood to the hood bands with self-tapping screws (provided).
- D. Fasten the hood to the wall.
–Place fasteners using the pre-drilled holes (wall fasteners not included).

HOOD SUPPORTS NOT SHOWN

NOTE: Install hood supports (if provided) at even intervals across header. Number and placement of hood supports will vary by width.



Section 4 - Installation

STEP 18 (INSTALL BRUSH SEAL (optionally purchased))

Brush Seal is an optional component purchased separately and does **not** come with door.

- A. Place curtain in fully closed position.
- B. Position brush seal against door lintel as shown, **Fig. 4-X**.
- C. Using appropriate fasteners (not provided) for your type lintel and with the holes drilled in the extrusion as a guide, fasten brush seal to lintel.

STEP 19 (INSTALL MOTION SENSOR (optionally purchased))

Motion Sensor is an optional component purchased separately and does **not** come with door.

- A. Follow the installation instructions accompanying the Motion Sensor.
- B. Install wiring per wiring diagram **FIG 5-OD** page 31.

STEP 20 (INSTALL LOOP DETECTOR (optionally purchased))

Loop Detector is an optional component purchased separately and does **not** come with door.

- A. Follow the installation instructions accompanying the Loop Detector.
- B. Install wiring per wiring diagram **FIG 5-OE** page 31.

STEP 21 (INSTALL RADIO CONTROLS (optionally purchased))

Radio Controls are an optional component purchased separately and does **not** come with door.

- A. Follow the installation instructions accompanying the Radio Controls.
- B. Install wiring per wiring diagram **FIG 5-OC** page 31.

STEP 22 (INSTALL WALL MOUNTED PUSH BUTTON (optionally purchased))

Wall Mounted Push Buttons are an optional component purchased separately and does **not** come with door.

- A. Install wiring per wiring diagram **FIG 8-J** page 45.




Fig 4-X

⚠ CAUTION

Making the checks outlined below will help to ensure that the *ADV* door and operator are installed properly.

CHECK LIST

- Is the door level, square and plumb?
- Are all the bolts tightened?
- Are limit switch sprockets properly aligned?
- ARE ALL BEARING AND SET COLLARS POSITIONED, ARE SET COLLARS AND BEARING SET SCREWS TIGHTENED?
- Has all the rigging equipment, ropes, straps, etc. been removed?
- Are all safety labels and tags in place?
- Are all cable connections in the proper locations?

Section 5 - Wiring

All Advanced Performance Service Door models are available in 220/240V AC 1-phase or 230V AC and 460V AC 3-phase as input voltage options. 575V AC 3-phase input power is available with the use of a 575V AC/460V AC step-down transformer for all Advanced Performance Service Door models. **YOUR LOCAL CODES MAY REQUIRE THAT THE INCOMING POWER TO YOUR ADVANCED PERFORMANCE SERVICE DOOR HAVE A LOCK-OUT / TAG-OUT EQUIPPED FUSED DISCONNECT SWITCH (TO BE FURNISHED BY OTHERS) WITHIN EYESIGHT OF THE DOOR'S CONTROL PANEL.**

Incoming power must meet all NEC and local building codes, plus be properly sized for the control panel's amperage rating on the nameplate. To reduce the risk of electrical shock, the chassis of the control panel must be properly grounded.

CAUTION

Advanced Performance Service Door Models must be supplied by a properly grounded voltage supply, e.g. 220/240 VAC 1-phase or 208/230/460/575 VAC 3-phase. Floating (Open Delta) ungrounded voltage supply sources should not be used. For 480 VAC, 240 VAC or 120 VAC unbalanced Delta systems should **NOT** be used. Voltage unbalance is a common occurrence on delta supply systems, which power both single and 3-phase load. This can lead to unequal voltages on each phase leg. Voltage unbalance can cause deterioration of motor performance such as loss of torque, overheating, decreases in the winding insulation life, and can cause motor starter contacts on the control panel to permanently "weld" closed. Voltage unbalance can be caused by inadequate conductor sizing, delta transformer sizing, excessive single phase loads, poor grounding or intermittent high resistance faults which may cause destructive over-voltages to occur. Any single phase loads should be evenly distributed as much as possible between the 3 phases. Consult a licensed electrician if you have any questions.

Wayne Dalton's warranty will not cover damage caused by failure of the motor, control panel or other electrical components due to the use of an inadequately grounded system.

Section 5 - Wiring

1. MAIN COMPONENT OVERVIEW, Fig. 5-C AND 5-D






Fig 5-C Control Panel Front Cover

Fig 5-D Control Panel Bottom/Wiring Access




Section 5 - Wiring

Fig 5-G Control Panel Contents (See also FIG 8-H)



Section 5 - Wiring


Fig 5-H Control Panel Wiring Diagram (480V)



Section 5 - Wiring


TO JUNCTION BOX

1. SENSING EDGE (WHITE)
2. INTERLOCK (GREEN)
3. NOT USED
4. PHOTOEYE RECEIVER (GRAY)
5. OPTION 1 (PINK)
6. OPTION 2 (RED)
7. NOT USED
8. NOT USED
9. NOT USED
10. COMMON (0V) (BLUE)
11. POWER (24V) (BROWN)
12. GND (GREEN/YELLOW)




TO ENCODER

1. 12V (BROWN)
2. A SIGNAL (WHITE)
3. B SIGNAL (BLUE)
4. 0V (BLACK)
5. PULSE (GRAY)



FROM JUNCTION BOX

Fig 5-1 Cables to Control Panel



ENCODER CABLE

Section 5 - Wiring

CAUTION

Ensure all openings into junction box are weather tight to prevent leakage.




Fig. 5-J JUNCTION BOX WIRING
Connections for most factory wired external control functions.

Section 5 - Wiring

STEP 1 PHOTOEYE ADJUSTMENT

1. Photoeye ADJUSTMENT (Retroreflective)

Photoeye wiring connections were completed in a previous step (Mounting Electrical components on page 18).

- Final adjustment of the Photoeyes will be made **after power is supplied to the door system**.
 - Verify the Photoeye green power LED is on, indicates power is on.
 - Loosen the mounting screws on Photoeye receiver and adjust position until the yellow LED on is steadily on. (LED will flash when receiving a weak signal)
 - Lock the mounting screws down, being sure not to move the Photoeyes out of alignment.





Fig 5-K



Photoeye Receiver Cable connects to Junction Box

Fig 5-L





Fig 5-M

Photoeyes is attached to the protective shield at the factory and must be mounted to the guides using the hardware provided.



Section 5 - Wiring

STEP 1 PHOTOEYE ADJUSTMENT

- 2. Photoeye ADJUSTMENT (Optional Thrubeam)**
 Photoeye wiring connections were completed in a previous step (Mounting Electrical components on page 18).
- Final adjustment of the Photoeyes will be made **after power is supplied to the door system**.
 - Verify the Photoeye transmitter LED is on, indicates power is on.
 - Loosen the mounting screws on both Photoeyes and adjust position until the LED on the receiver is steadily on.
 - Lock the mounting screws down, being sure not to move the Photoeyes out of alignment.



* Photoeye cables are wired at the factory with a M12 connector. wire colors are for reference.
NO FIELD WIRING REQUIRED.



Photoeyes is attached to the protective shield at the factory and must be mounted to the guides using the hardware provided.

Section 5 - Wiring

STEP 2 ENCODER WIRING CONNECTIONS AND SETTINGS

- A) Attach one end of the M12 encoder cable to the encoder.
- B) Attach the other end of the M12 encoder cable to the Control Panel.









Fig 5-0b Encoder Cable


Section 5 - Wiring



LOOP DETECTOR DEFAULT SETTINGS



WHITE BOX
INDICATES SETTING



STEP 5 OPTIONS WIRING AND SETTINGS

-Wire the supplied cables to the following options as shown in **FIG 5-OC, FIG 5-OD, FIG 5-OE.**

A. For the radio receiver, wire the supplied receiver load into the control unit from MAN1 to 24VDC (blue terminal).

CAUTION

Door will open/close once connected.

1. Access the menu and navigate to system config-> Inputs-> Man1-> Logic.
2. Select NC parameter and exit the menu.

B. The motion detector and loop detector can be operational once wired to the junction box. They are wired for the default configuration.

1. To update the auto close timer, access the express menu->Auto1 Timer.

Section 5 - Wiring

REFERENCE: CONVENTIONAL WIRE ROUTING

NOTE: Components/component locations are shown here for reference only. Some parts not shown for clarity. Your unit installation and wire routing may be different.




Fig 5-P

NOTE: Installed wire routing for example only.

Wiring Check List

After completing the instructions contained in this section, check:

WARNING

Making the checks outlined below will help to ensure that the unit is wired properly.

- CHECK**
- Double check that all connections are tight.
 - Check all cables are secured (not hanging loose where they might become an interference).
 - Ensure there are no loose tools or materials inside the Control Panel or Junction Box.

Section 6 - Initial Startup Procedure


STEP 1 APPLY POWER (LINE VOLTAGE)

Turn the disconnect handle Clockwise to the ON position in order to apply power to the Control Panel. A blue splash screen will pop up displaying the default profile, and controller data (consists of serial number, output capacity, software version, etc). Verify the system motor rating, and power ratings correspond with each other.

NOTE: The system information can also be accessed in the SYSTEM STATUS > OVERVIEW menu. (see page 35-37)

STEP 2 VERIFY PHOTOEYE ALIGNMENT

- A. Verify the RED LED, on the Photoeye Transmitter, is steady ON. If the RED LED is **NOT** ON refer to Troubleshooting, Section 7
- B. Verify the RED LED, on the Photoeye Receiver, is steady ON. If the RED LED is **NOT** ON, loosen the mounting screws and adjust the Photoeye positions until the RED LED is steady ON. Tighten the mounting screws. If the RED LED does **NOT** come ON review the Photoeye installation steps on page 17. Refer also to Troubleshooting, Section 7.



⚠ WARNING

All Entrapment Protection Devices are **OFF** in Emergency Jog and the Limits are **NOT SET**. Devices **OFF** while in Emergency Jog include: Edge Contact, Photoeye, Wall push buttons, Radio Control, Limit Sensors, Loop Detector, or any motion sensor used as either an actuator or an Entrapment Protection Device. Only the Interlock remains active.

Emergency Jog is the manual control for momentary operation of door via ARROW buttons on the membrane keypad or on the control unit.

USE CAUTION! WHILE SETTING UP THE DOOR IN THIS MODE. Do NOT use Emergency Jog for general door operation.

Section 6 - Initial Startup Procedure

STEP 3 INITIAL/LIMIT SETUP

The first time the controller is powered on, you must first set the limits. The LED screen will flash with the error E17, and you must reset the limits. This will also occur whenever the encoder is disconnected from the controller. The encoder, photoeyes, sensing edge, and interlock switch must be connected before the limits can be set. If, for any reason, the limits cannot be set, please refer to troubleshooting section 7.

- A. To enter the Menu, press and hold the OPEN, STOP, CLOSE membrane buttons for 3 seconds. A count down timer on the top left corner of the LED screen will display the remaining time left to hold. Refer to **Fig 6-A** for the complete menu structure.
- B. Holding the Stop button for 1 second will go back up a level in the Menu. Continuing to hold the STOP button will continue to go back up the menu structure until the main screen.
- C. Once in the main screen, a 25 second countdown timer will show on the upper left hand corner. This countdown timer displays how long until the OPEN/STOP/CLOSE buttons will no longer give access to the MENU. Once inside the menu, use the **OPEN button to scroll up, STOP button to enter, and CLOSE to scroll down**. Pressing OPEN/STOP/CLOSE immediately exits the counter.

Note: Instead of using the front panel buttons one can access the menu from the control unit using menu/enter, the ▲, and ▼ buttons.

1. Enter the Menus

2. Scroll down until you reach the LIMIT SETUP and hit enter.
3. Scroll down and enter into Quick Setup. A code request screen will appear. Enter the 3 digit passcode to gain access by scrolling up or down. Your passcode is located on a separate addendum.

NOTE: Do not display or freely give out the passcode.

4. Follow the prompts in order to set the open and close limits on the door. During this time, use the OPEN, CLOSE buttons to move the door. Again, the STOP button will be used as the ENTER function. If no error has occurred, it will then display QUICK SETUP DONE, otherwise if failed; QUICK SETUP ABORTED and it must be redone. Refer to Troubleshooting section 7 if required.

NOTE: When setting the position, the encoder count will be displayed. Verify the encoder count increases when the door is moving in the up direction, and does not roll over to the negative position.

STEP 4 VERIFICATION

Test each sensor to make sure the controller recognizes the fault.

- A. Photoeyes -Obstruct the beam with a solid object. Photoeye should reverse door direction.
- B. Sensing edge -Place a solid object, taller than 12", on the floor and close the door. Sensing edge should reverse door direction on contact with object.
- C. Interlock switch - This is a constant activation sensor, pull the hand chain and the door should not operate and a fault display.

NOTE: all faults and sensor activations are logged into the Fault Log. Access this through the menu SYSTEM STATUS > FAULT LOG in the Controller Menu. To clear faults hold the STOP button for 1 second once the fault has been fixed.

Section 6 - Initial Startup Procedure


MENUS

1 EXPRESS MENU

The Express Menu is accessed by scrolling up, when at the idle screen or after exiting the menus. The express menu contains display options, timers, settings reset, and the emergency JOG. The timer functions in the Express Menu are shortcuts to timers in the system configuration menu without the need of a passcode.

Note: Not all Menus are accessible. Passcodes are required to access higher systems operations.

Fig 6-A



Section 6 - Initial Startup Procedure

MENUS

2 SYSTEM STATUS MENU

The System Status menu is read-only and provides parameter status displays for use in setup and troubleshooting. The options of the System Status menu are shown and described below. The controller is fully operational within this menu, allowing real-time parameter updates. To use the System Status menu:

- A. Enter the System Status menu
- B. Scroll down and highlight a menu option.
- C. Enter to view the highlighted option.
- D. Press and hold STOP or ENTER when finished to return to the System Status menu.
- E. Repeat to view other parameters if desired.

Overview

Photocell 1: OK
Safety Edge 1: OK
Position: 123

Overview displays status and current position of Photocell and Sensing edge (reversing edge)

- 1. To view status and current position of photocell
- 2. Sensing edge 2, scroll up.

Position

Position: 123
Battery OK

Position shows the internal door position count. The battery level and status are shown

Safety Edge

SE1: Idle
SE2: OFF

Safety edge shows the status of the sensing edges (SE).

Inputs

X2:

X4:

Inputs provides an overview of the controller inputs. Box is marked if the corresponding controller input is active.

Outputs


Relay:

NPN:

Outputs provides an overview of the controller outputs. Box is marked if the corresponding controller output is active.

Section 6 - Initial Startup Procedure

MENUS




Log 1 of 10
Error: E10
On Cycle: 045

Fault log displays error code and door operation cycle for the last 10 faults. Scroll up or down to navigate through the fault log.




Cycle Counter
85421
Operations

Cycle counter shows the number of operating cycles the door has completed (open/close = 1 cycle). Note: This is already shown by default at the top left corner in the main screen.




Temperature
330*
L ————— H

Temperature shows the internal temperature of the DGII Controller. This is a raw analog value and does not represent degrees centigrade or Fahrenheit. A display on the bottom graphically approximates either a Low or High temperature



DC Link
330V
300 - 370V DC

DC Link shows the internal DC Link voltage along with the acceptable range.



Int Levels
Int 12V: 11.5V
Int 24V: 22.0V

INT Levels shows the control's actual internal supply voltages.

Section 6 - Initial Startup Procedure

MENUS

3 PROFILE SELECTION MENU

The profile selection is done at the factory by default. Profiles can be selected based on the door the controller is operating. The profile is protected by a passcode, and can only be changed by a Wayne-Dalton service representative. All settings are lost and reverted back to defaults when the profile is changed. Profiles can be accessed through the main menu under Profile Selection.

4 LIMIT SETUP MENU


Individual limits can be updated manually, however; the best option is to use the quick setup process as discussed earlier. The door will not be operational when setting limits. Limit settings are as described:

⚠ WARNING

All Entrapment Protection Devices are **OFF** when setting limits. Devices **OFF** while setting Limits include: Edge Contact, Photoeye, Wall push buttons, Radio Control, Limit Sensors, Loop Detector, or any motion sensor used as either an actuator or an Entrapment Protection Device. Only the Interlock remains active. **USE CAUTION! Do NOT use for general door operation.**

To configure the Limit Settings manually after using Quick Setup, select each individual position listed below from the Limit Setup menu, then move the door to the desired position. Store the position by pressing STOP or ENTER when finished. The display shows Stored and returns to the previous menu.

- Closed: Door fully closed.
- Pre Closed: Position where door changes to pre-closing speed during close.
- Pre Open: Position where door changes to pre-open speed during open.
- Open: Door fully closed.
- Open Part 1: Partially open position 1. Door opens to this position when a part 1 open input is active. (default: 75% of door open limit)
- Open Part 2: Partially open position 2. Door opens to this position when a part 2 open input is active. (default: 50% of door open limit)
- Rev. Edge OFF: Sets door position where sensing edge check is turned off: the limit where the reversing sensing edge should be ignored.
- Photocell Off: Sets door position where photocell should be ignored.



Section 6 - Initial Startup Procedure

MENUS

5 SYSTEM CONFIGURATION MENU

This menu contains all editable parameters on the door system. A passcode is required in order to change the settings. The door will not operate when inside the menu.

A. Timers

1. Contains all the same timers in the Express Menu.
2. Setting the timer to 0 disables the timer.

B. Outputs - Configurable relay activation based on custom door status/events. Table on page 40 lists all available status/events.

C. Inputs - Inputs with configurable actuator functions. Table on page 39 lists all functions available with each input.

D. Position sensor -Do not update/menu is not used

E. Reference -Do not update/menu is not used.

F. Sensing edges -1 or 2 Sensing edge select as well as Sensing edge Type.

G. Photoeyes -Do not update/menu is not used

H. Motor Configuration - Do not update / Engineering use only.

I. Frequencies - Do not update / Tech Services use only.

J. Ramps - Do not update / Tech Services use only.

K. DG-XNET -Do not update / Menu not used.

L. Options -Do not update / Menu not used.

M. System -Do not update / Engineering use only.

6 CONFIGURATION - INPUTS/OUTPUTS

A. Inputs. There are 3 parameters that can be set. Refer to **FIG 6-C** (close up view of Input relays)

1. Function -A list of functions can be selected to determine how the input should operate the door.
2. Name -a name can be applied to the specific function
3. Logic -The logic for activation of the door can be chosen. Either Normally Open (0VDC ->24VDC) or Normally Closed (24VDC ->0VDC).

B. Outputs. Refer to **FIG 6-D** (close up view of Output relays)

- 1 Function -list of functions can be selected to activate the output relay
2. The output is dependent on the input wired into the relay pins 2, 5, 7, 9.
3. Output relays 1 & 2 consist of two relay outputs, a NO and NC. Output Relays 3 &4 contain only NO relay activation.

Section 6 - Initial Startup Procedure

MENUS

INPUT SIGNAL	ACTIVATION DESCRIPTION`
Manual	Momentary activation opens door unless the door is already at an open position. In this case, the door will close. 1) If the Manual timer is set to a value greater than zero, the controller delays closing of the door until the timer expires.
Open	Opens the door to fully open position when activated.
Auto 1	Momentary activation opens door to the fully open position limit. Upon deactivation the controller delays the door for the duration of the Auto timer. If reactivated during this time delay, the timer will be reset and will begin to decrement when the input is again deactivated. Upon expiration of the timer, the controller closes the door to fully closed position. If timer is not used, the door will stay in the open position when activated.
Stop	Momentary activation stops the motion of the door. This input uses the Stop Deceleration Ramp set under the System Config menu. This input is also used to clear certain error conditions.
Close	Closes the door to fully open position when activated
Emergency Stop	Activation immediately halts the door in motion. This input uses the Emergency Deceleration Ramp set under the System Config menu.
Sensing edge	Activation during a closing cycle stops the door and then reverses the door motion back to the fully open position limit. An "E10 Sensing edge Activated" error occurs.
Photoeye	Activation during a closing cycle stops the door and then reverses the door motion back to the fully open position limit.
Lock Open	Activation causes the controller to hold the door at the fully open position limit. The input must be continuously activated to maintain the locked open state. Deactivating this input unlocks the door and allows normal operation.
Lock Close	Activation causes the controller to hold the door at the fully closed position limit. The input must be continuously activated to maintain the locked open state. Deactivating this input unlocks the door and allows normal operation.
Open Jog	Activation of this input moves the door in the direction of the fully open limit at Jog speed. Deactivating this input stops the door in motion. Activation during closing does not open or stop the door.
Close Jog	Activation of this input moves the door in the direction of the fully closed limit at Jog speed. Deactivating this input stops the door in motion. Activation during opening does not close or stop the door.
Breakaway	Activation halts door motion.
Open Position 1	Activation opens the door to the partial open 1 position limit. If activated during closing, door will reverse to 1 position limit.
Open Position 2	Activation opens the door to the partial open 2 position limit. If activated during closing, door will reverse to 2 position limit.
Open Part 1 Auto	Activation opens the door to partial open 1 position limit. The controller then delays the door for the duration of the Auto Timer. Upon expiration of the timer, the door closes fully.
Open Part 2 Auto	Activation opens the door to partial open 2 position limit. The controller then delays the door for the duration of the Auto Timer. Upon expiration of the timer, the door closes fully.
Flip Flop	Activation reverses the door operation. If door is closed, activation opens the door and vice versa. When door is closing and activated, the door reverses and begins opening and vice versa.
Man Part 1	Activation opens the door to the partial open 1 position limit, if not already at this position. If the door is already at this position, the door closes.
Man Part 2	Activation opens the door to the partial open 2 position limit, if not already at this position. If the door is already at this position, the door closes.





Fig 6-C

Section 6 - Initial Startup Procedure

MENUS

INPUT SIGNAL	ACTIVATION DESCRIPTION*
Door Moving	Output is active when the door is in motion.
Door Not Moving	Output is active when the door is not in motion.
Door Open	Output is active when the door is at the fully open position.
Door Closed	Output is active when the door is at the fully closed position.
Door Not Closed	Output is active when the door is above the fully closed position.
Door Open Partial	Output is active when the door is at open part 1 position.
Door Opening	Output is active when the door is moving in the open direction.
Door Closing	Output is active when the door is moving in the close direction.
Delay to Close	Output is active when the Delay To Close timer is greater than zero and the door is commanded to close. The output remains active for the duration of the Delay To Close timer.
Delay to Open	Output is active when the Delay To Open timer is greater than zero and the door is commanded to open. The Open button must remain active until the Delay To Open timer has expired, the output will be active during this time. Upon expiration of the timer, the door opens and the output is deactivated.
Auto Close Active	Output is active for the duration of the Auto or Man timer during an auto close sequence.
System Error	Output is active when DGII is in any error condition.
Pre Warning Active	Output is active for the duration of the Auto Timer and during any close sequence.
Open Alarm Active	Output is active when Open Alarm Timer is greater then zero.

Fig 6-D



Section 6 - Initial Startup Procedure

MENUS

7 INFORMATION MENU

1. How to use the keypad to retrieve operation events, fault/shutdown messages, and system status


(Also see Section 7—Troubleshooting)

• **With the unit idle**

- Enter the System Status menu.
- Scroll through the list of choices until you reach the Fault Log menu and enter.
- Scroll through the list until you reach the information you're looking for.
- When finished exit the menus and return to the main screen.

NOTE: The items in the Fault Log are listed in reverse chronological order with number 1 being the most recent and the highest number being the oldest.

- If NO keys are pressed for 120 seconds, display will exit back to the main menu.
- Motion can occur and panel responds normally to inputs while in the System Status Menus.



Set Up Check List

⚠ CAUTION

Check ALL items below to ensure that the Control Panel is installed and operating properly.

CHECK

- The door operates using all installed control devices.
- The door runs to its full open and full closed positions.
- The Entrapment Protection Device(s) will reverse a closing door when activated.
- The proper Actuator selections are made to activate timers.

If the panel is in a location where public access is possible, install a means to limit access to the inside of the panel.

⚠ WARNING

To prevent injury, entrapment devices must be tested to insure proper operation.

Section 7 - Troubleshooting





Fig 8-H

Section 7 - Troubleshooting

GENERAL

TROUBLE	POTENTIAL CAUSE	NOTES / CORRECTIVE ACTION
Door will not move	Door may be in Shut Down mode. Fix issue.	Press stop key to clear fault.
	No power	Check motor wiring, power line, system rating.
Timed Close not functioning	Timer is set to 0.	Verify or update specific timer in express menu..
	Timer condition not met.	Verify door is at open close limits, or condition is met.
Auto 1/ Manual 1 Function not working	Wiring or connection loose, signal not reaching controller.	Verify connections.
	Auto 1/Man 1 not selected as function.	Verify chosen input function.
On key release, door stops or reverses	One of the sensor inputs activated.	Verify sensor inputs.
Timed Close quits after a few reverses	After a factory set number of failed attempts, usually three, the door will stop attempting to Time Close after a reversal. This is normal door function.	Door will reverse a Timed Closed door without counting the first reversal as a failed attempt. NOTE: If Entrapment Prevention Inputs cause reversals in the meantime, the reversals will continue to count as failed attempts and stop the close timer after three tries.
Wall push button not responding.	Wiring and firmware setting incorrect.	Common should be set to 24V Stop is set to NC in firmware (System config > Inputs) Open is set to NO. Close is set to NO. Refer to Fig 8-J page 45
General service Due: XXXXX	Routine service interval has elapsed.	Contact distributor for required maintenance.
Major service Req'd XXXXX	Required maintenance interval has elapsed.	Contact distributor for required maintenance.
Door stops for no reason, or acts differently than before - No errors displayed, only shows IDLE at status	A brownout or short has affected the controller	Use the disconnect switch to turn off the power, wait until the unit shuts off, then turn it back on (hard reset). -Contact customer service if it is still an issue.
	Possible overheat	Check fault log
One of the options to the Junction Box does not operate as expected	Connection to the Junction Box is incorrect	Ensure the Junction Box connections are correct (Via Manual) 1. Radio Remote Receiver is wired to OPTION 2 (or to Manual1 input) -A 10 kohm load is also needed to be wired from the Manual1 input to a 24VDC connection (part of the kit when delivered). 2. Loop Detector or Motion Detector is wired to Option 1 (or to an Auto1 input) NOTE* Both can be wired, but one needs to be wired directly to the Control Unit (regular wire can be used)
Quick setup aborted	Fault occurred when setting limits	1. Fix faults in system. 2. Make sure Position count increases when setting door to open limit (door direction incorrect). 3. Restart Quick Setup.
Door limits have shifted	Encoder fault/failure	1. Verify Encoder connections. 2. Verify magnet in encoder has not moved and has not rubbed against the encoder. 3. Reset limits.

Section 7 - Troubleshooting



CONTROL PANEL STATUS MESSAGES

MESSAGE DISPLAYED	CAUSE	NOTES / CORRECTIVE ACTION
-----	Displayed if no message code is present in the Event or Error Log.	Contact service representative.
STATUS		
Idle	Door at rest, not at open, close, mid limits.	Displayed when door is motionless in Idle and not at open, close, open P1 limits. Door stopped using the STOP key.
STATUS		
Count down	Door at rest and counting down to timed close or open.	Time remaining in seconds is displayed.
STATUS - OPENING		
Opening	Door opening.	Displayed while door is opening from activation.
STATUS - CLOSING		
Closing	Door closing.	Displayed while door is closing from activation.
STATUS - STOP		
Stop	Door stopping.	Displayed while door is stopping from activation.
STATUS		
Locked	Incorrect pass code input.	Displayed when the wrong pass code is entered
Closed	Position at close limit.	
Open	Position at open limit.	
Open P1	Position at 75% of open limit.	
Open P2	Position at mid limit.	

Section 7 - Troubleshooting

CONTROL PANEL ERROR MESSAGES - INVERTER ERROR CODES

CODE	DESCRIPTION	PROBLEM	POSSIBLE SOLUTION
INV_ERROR_UU	DC Link low (Top Priority)	The incoming mains voltage is too low	View System Status - DC Link to check that the voltage is within the range shown.
INV_ERROR_OU	DC Link high (Medium Priority)	Either the incoming mains voltage is too high or the deceleration rate is too short	View System Status - DC Link to check that the voltage is within the range shown. Decrease the deceleration ramps.
INV_ERROR_OC1	Overcurrent 210% (Low Priority)	The motor current exceeds the inverter rating by 210%	View the Motor Current display to check the current delivered to the motor. Check the motor nameplate data to confirm that the correct controller model is being used. Check for mechanical obstruction or damage.
INV_ERROR_OC2	Overcurrent 150%/30 sec (Low Priority)	The motor current exceeds the inverter rating by 150% for more than 30 seconds	View the Motor Current display to see the current delivered to the motor. Check the motor nameplate data to confirm that the correct controller is being used. Check for mechanical obstruction or damage.
INV_ERROR_OC3	Overcurrent during acceleration	Overcurrent while accelerating	View the Motor Current display to see the current delivered to the motor. Decrease the acceleration ramps
INV_ERROR_OC4	Overcurrent DC/Brake (Medium Priority)	Overcurrent while DC braking	View the Motor Current display to see the current delivered to the motor. Decrease the DC Brake level.
INV_ERROR_OC5	Peak overcurrent (High Priority)	Severe overload	Check for: a short in the motor cable stalled motor mechanically or electrically damaged motor. If equipped with a parking brake, ensure that it is being released. Decrease the Boost parameters.
INV_ERROR_OH	Controller overheat (High Priority)	The inverter is overheated	View System Status - Temperature to check that the reported temperature is within range. Check ventilation and ensure fan, if present, is operating. Reset the controller and confirm that the fan operates for 1 second during the power-up routine. Reduce the duty cycle of the door.
INV_ERROR_12V	Low internal 12v (Top Priority)	The internal 12V DC power supply voltage is too low	View the System Status - Int Levels to check that the voltage is within range. Check I/O wiring for shorts.
INV_ERROR_24V	Low internal 24v (Top Priority)	The internal 24V DC power supply voltage is too low	View the System Status - Int Levels to check that the voltage is within range. Check I/O wiring for shorts.

Section 7 - Troubleshooting

CONTROL PANEL ERROR MESSAGES - DOOR CONTROL ERROR CODES

CODE	DESCRIPTION	PROBLEM	POSSIBLE SOLUTION
E01	Slip error (Low Priority)	Mechanical overload (Slip Monitoring) or missing signal from encoder.	Check door for obstruction. Ensure the pulse output from the encoder is connected to terminal P2 on the controller. Verify that the encoder pulse output is set correctly.
E02	Direction Error - occurs during setup only (Low Priority)	The direction of the motor is incorrect. The encoder count must increment positively while the door is moving in the open direction.	Use the Motor Direction parameter to set the correct direction for the motor and encoder.
E03	No Signal From Pulse Generator - occurs during setup only. (Low Priority)	No pulse input detected from the encoder.	Check door for obstruction. Ensure the pulse output from the encoder is connected to terminal P2 on the Controller. Verify that the encoder pulse output is set correctly.
E04	Speed Error	Door moves faster/slower than Expected	Check door for obstruction.
E05	N/A		
E06	N/A		
E07	Run Timer Exceeded (Low Priority)	The Run Timer has expired.	Check the Run Timer parameter to ensure a correct value.
E08	Sensing edge Test Fail (Medium Priority)	The Sensing Edge test has failed	Check the connections from the reversing edge to the controller. If using the Seywave wireless system, check operation of connected host and remote door sensor.
E09	Sensing edge Connection (Medium Priority)	The Sensing Edge connection cannot be verified.	Check the connections from the reversing edge to the controller. If using the Seywave wireless system, check operation of connected host and remote door sensor. Verify Sensing edge is not activated.
E10	Sensing edge 1 Activated (Low Priority)	The Sensing Edge has been activated	Check for obstruction in door's path.
E11	Sensing edge 2 Activated (Low Priority)	The Sensing Edge has been activated	Check for obstruction in door's path.
E12	Lifting Force Exceeded (Low Priority)	The torque limit has been exceeded	If the torque limiting feature is being used, adjust the Torque Limit parameter to suit the application.
E13	No Encoder movement	Encoder did not move when expected	Check for obstruction. Check connection from Encoder to Motor.
E14	Absolute Encoder Comm Loss (Top Priority)	Communication with the absolute encoder has been lost.	Check the connections between the encoder and the controller.
E15	Installation Fault (Low Priority)	An error occurred during Quick Setup	Re-perform Quick Setup
E16	Encoder fault	Encoder communication is not correct	Check Encoder. Verify connections.

Section 7 - Troubleshooting

CONTROL PANEL ERROR MESSAGES - DOOR CONTROL ERROR CODES

CODE	DESCRIPTION	PROBLEM	POSSIBLE SOLUTION
E17	Reset Limits (HIGH PRIORITY)	The position limits cannot be verified	Perform a Quick Setup
E18	Wireless Airlock Failed to Authorize Opening (Low Priority)	The controller failed to receive an Airlock request acknowledgement.	Check opposite controller to ensure that it is operational. Check that both controllers have been wirelessly connected together and that each controller has Wireless and Airlock enabled. Disconnect controllers and run a discovery to reconnect controllers.
E19	Wireless No Response	There was no response from the onboard wireless	Ensure that the Wireless is Enabled then power cycle the controller.
E20	Backroll error	Door movement when at idle state	Verify there are no obstructions, verify motor gear box is functional.
E21	Option - Seywave OCS Remote Timeout	A paired Seywave wireless O/C/S remote has timed out.	Check the remote for operation. Refer to supplied Seywave Wireless manual for troubleshooting.
E22	Option - Seywave DS Remote Timeout	A paired Seywave wireless Door Sensor remote has timed out.	Check the remote for operation. Refer to supplied Seywave Wireless manual for troubleshooting.
E23	Option - Seywave DS Connection Fault	A paired Seywave wireless Door Sensor remote has reported a connection fault.	Check the connection and remote for operation. Refer to supplied Seywave Wireless manual for troubleshooting.
E24	N/A		
E25	Manual Crank input active (Medium Priority)	Chain hoist is engaged.	Disengage chain hoist.
E26	Overtravel error (HIGH PRIORITY)	Door moves beyond limits.	Reset limits
E27	Photoeye connection test fail (Medium Priority)	Monitored Photoeye connection test failed.	Check photoeye connections
E28	Photoeye 1 activation (Low Priority)	Photoeye 1 has detected an obstruction.	Check for obstructions in photoeye path
E29	Photoeye 2 activation (Low Priority)	Photoeye 2 has detected an obstruction	Check for obstructions in photoeye path
E30	Input Timer Exceeded	Input activation lasting longer than 2 minutes.	Verify wall buttons are not stuck. Check connections for a short.

CONTROL PANEL ERROR MESSAGES - ERROR CODE PRIORITY LEVELS

Priority Level	Reset Condition	Comment
Low	Activation input	Can also be reset by higher priority reset conditions
Medium	Stop, E-Stop or Menu/Enter button pressed	Can also be reset by higher priority reset conditions
High	Menu/Enter button pressed and held for 2 seconds.	Screen Flashes
Priority Reset Limits	Successful Quick Setup	Auto-clears when limits are set
Priority Encoder Connection	Communication restored between encoder and controller	Auto-clears when fault no longer exists
Priority INV_ERROR_UU	Incoming main voltage is within range	Auto-clears when fault no longer exists
Priority INV_ERROR_12VInternal 12V	Internal 12V DC level is within range	Auto-clears when fault no longer exists
Priority INV_ERROR_24V	Internal 24V DC level is within range	Auto-clears when fault no longer exists

Section 8 - Service and Maintenance

NOTE: Table 9–A provides a schedule of Service and Maintenance items.

INSTALLATION DATE: _____ INSTALLER INITIAL: _____
 SERVICE ITEM SERVICE INTERVAL (frequency)

	EVERY DAY	EVERY 6 MOS. or 50,000 CYCLES	EVERY 12 MOS. or 100,000 CYCLES
General Inspection		•	
Limit Switch Chain Tension and Alignment		•	
Manual Operation of Door		•	
Sensing Edge & Photo Eye systems	•		
Mounting Bolt Tightness			•
Motor Brake Gap and Motor			•
Check Limit Position		•	
Check Emergency Brake Activation List		•	

Table 9–A

CAUTION

Failure to perform specified service and maintenance may result in an unsafe condition, will void limited warranty, and may result in premature failure of the unit. Service and Maintenance are necessary to ensure safe operation of the ADV door.

Service Interval Message

- When cycles indicate service is required, the panel will display which service interval has been reached.
- Once service is completed, clear the service message by going into System Configuration ->System -> Clear Service

Maintenance Interval Message

- Upon reaching 280,000 door cycles (580,000 & 880,000, etc.), the panel will display which maintenance interval has been reached.
- Contact your distributor to have required maintenance performed.
- Once service is completed, clear the service message by going into System Configuration ->System -> Clear Service.

General Inspection

- Visually inspect wiring conduit and cables.
- Inspect fixtures such as: Bearings, conduit boxes, hood, gear box (for oil leakage), motor.
- Inspect safety labels, placement and condition.
- Lubricate guides with paste wax or silicone spray.

Manual Operation of Door

- Inspect door alignment and level.
- Inspect slats and endlocks for damage.
- Inspect guides, Sensing edge and hood for damage.

Mounting Bolt Tightness

- Check fasteners anchoring headplates and door guides to wall.

Sensing edge & Photoeye systems

- Test Sensing edge activation daily.
 - Place a solid object, higher than 12", on floor and close door. Sensing edge should reverse door direction on contact with object.
- Test Photoeye activation daily.
 - Obstruct the Photoeye beam with a solid object. Photoeye should reverse door direction.

Check Limit Position

- Verify the door stops at correct open position.
- Verify that door closes fully without excessive "stacking" of curtain in guides.
- Verify approach speeds provide for smooth starts and stops.

NOTE: Keep records of all service and maintenance.

Section 9 - Illustrated Parts Breakdown

Parts Drawing

NOTE: Fasteners and some parts not shown for clarity.

NOTE: Components and component locations are shown here for reference only. Your unit installation and component locations may be different.




Fig 10-A

PARTS LIST on next page

Section 9 - Illustrated Parts Breakdown

Table of Part Numbers

BEFORE ORDERING PARTS LOCATE YOUR ORIGINAL DOOR NUMBER FOUND ON THE NAMEPLATE ATTACHED TO YOUR BOTTOM BAR

ITEM	DESCRIPTION	PART NUMBER	ITEM	DESCRIPTION	PART NUMBER
1	COMPLETE CURTAIN ASSY.	INQUIRE			
2	SLAT	INQUIRE			
3	ENDLOCK / WINDLOCK	307648/307649	19	JUNCTION BOX	308694
4	COMPLETE BOTTOM BAR ASSY.	031-0001	20	CONTROL PANEL	308695
5	>SEYWAVE WIRELESS MODULE	820315	21	PHOTOEYE ASSY. PAIR (RETROREFLECTIVE)	810187
6	>WIRELESS MONITORED SAFETY EDGE	810265		>RELFECTOR, RETROREFLECTIVE SENSOR	500374
7	GUIDE ASSEMBLY	308156		>BRACKET, SENSOR	500375
8	HI-USE POLYURETHANE WEAR STRIP	607116		>RETROREFLECTIVE SENSOR	500376
	>GUIDE WEATHERSTRIP, BLADE TYPE (NOT SHOWN)	086695		>BRACKET	810188
	>WEATHERSTRIP RETAINER, ALUMINUM (NOT SHOWN)	086620		>PHOTOEYE CABLE (NOT SHOWN)	308697
9	HEADPLATE ASSY., NON-DRIVE	810264	22	PHOTOEYE ASSY. PAIR (OPTIONAL THRUBEAM)	810187
10	HEADPLATE ASSY., DRIVE	810264		>PHOTOEYE TRANSMITTER	107322-0005
11	FLANGE BEARING	600261		>PHOTOEYE RECEIVER	107322-0005
12	GFA MOTOR UNIT	INQUIRE		>PHOTOEYE CABLE (NOT SHOWN)	308697
13	BARRAL ASSY.	810168	23	HOOD ASSY.	702-1254
14	SET COLLAR	604297-1125	24	SENSING EDGE WARNING LABEL	607873
15	KEY .375 X .375 X 9"	082090	25	SAFETY LABEL	356994
			26	MOTOR COVER	003-1778
			27	NON-DRIVE END COVER	003-1713
			28	ENCODER BRACKET	810239

Table 10-B



Rolling Steel Models 800 and 800C ADV Advanced Door System Option

Limited Warranty

Wayne Dalton, a division of Overhead Door Corporation, ("Seller") warrants to the original purchaser of the rolling steel service door models 800 and 800C with Advanced Door System Option ("Product"), subject to all of the terms and conditions hereof, that the Product thereof will be free from defects in materials and workmanship under normal use for the following periods, measured from the date of installation:

- **Seller warrants all mechanical door system components and the control panel hardware for a period of 60 MONTHS**
- **Seller warrants premium powder coat with hardening additive finish for a period of 60 months against blistering, flaking or peeling of the finish**

Seller's obligation under this warranty is specifically limited to repairing or replacing, at its option, any part which is determined by Seller to be defective during the applicable warranty period. Repair or replacement labor for any defective Product component is excluded and will be the responsibility of the purchaser.

This warranty is made to the original purchaser of the Product only, and is not transferable or assignable. This warranty does not apply to any unauthorized alteration or repair of the Product, or to any Product or component which has been damaged or deteriorated due to misuse, neglect, accident, failure to provide necessary maintenance, normal wear and tear, or acts of God or any other cause beyond the reasonable control of Seller. This warranty does not apply to any damage or deterioration caused by door slats rubbing together as the door rolls up upon itself or caused by exposure to salt water, chemical fumes or other corrosive or aggressive environments, whether naturally occurring or man-made, including, but not limited to, environments with a high degree of humidity, sand, dirt or grease. This warranty on finish does not apply if the Product is installed within 2000 meters of any ocean or other body of saltwater. This warranty specifically excludes any damage resulting from scratching, abrasion or impact by any hard object, and any fading or color change which may not be uniform due to unequal exposure of the curtains to sunlight or other elements. Wearing away of the painted surfaces of the Product is a common occurrence resulting from the curtain repeatedly coiling upon itself and uncoiling during normal usage (See DASMA #274), and is specifically excluded from this warranty. Seller does not warrant that the Product software will provide error-free operation or be free from defects.

THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT SHALL SELLER BE RESPONSIBLE FOR, OR LIABLE TO ANYONE FOR, SPECIAL, INDIRECT, COLLATERAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL DAMAGES, even if Seller has been advised of the possibility of such damages. Such excluded damages include, but are not limited to, loss of goodwill, loss of profits, loss of use, cost of any substitute product, interruption of business, or other similar indirect financial loss.

Claims under this warranty must be made promptly after discovery, within the applicable warranty period, and in writing to the Seller or to the authorized distributor or installer whose name and address appear below. The purchaser must allow Seller a reasonable opportunity to inspect any Product claimed to be defective prior to removal or any alteration of its condition. Proof of the purchase and/or installation date, and identification as the original purchaser, may be required. This Warranty is not valid unless the fields below are completed by the installer at the time of installation.

Door Type: _____

Customer Name (Original Purchaser): _____

Customer Installation Location: _____

Order # _____ Date of Installation: _____

Name of Dealer/Installer: _____

Signature of Dealer/Installer: _____

Rev. 06.2012