

Wayne Dalton, a division of Overhead Door Corporation
P.O. Box 67 Mt. Hope, OH 44660
www.Wayne-Dalton.com

Use this insert in conjunction with the main door Installation Instructions and Owners Manual. All WARNINGS and CAUTIONS listed in the main Installation Instructions and Owner's Manual are applicable to this supplemental insert.

⚠ WARNING

FAILURE TO ENSURE TIGHT FIT OF CABLE LOOP OVER MILFORD PIN COULD RESULT IN COUNTERBLANCE LIFT CABLE COMING OFF THE MILFORD PIN, ALLOWING THE DOOR TO FALL, POSSIBLY RESULTING IN SEVERE OR FATAL INJURY.

Attach the cable loop at the end of the counterbalance lift cable over the milford pin. Place one 3/16" roller spacer on the short stem track roller, and insert the roller into the bottom corner bracket/roller carrier. Insert a long stem track roller in the double end hinge at the top of the bottom section. Repeat for the right hand side.

