

# Waynegard Series Installation Instruction Insert for 3" Non-Symmetrical U Bars

**NOTE:** All Thermogard II® & Thermowayne II™ ( 9600/9900 series) glazed top doors 13'-0" wide or greater will now be supplied with a 3" non-symmetrical ubar for the top section.

With the section faced down:

1. Place the 3" non-symmetrical ubar over the integral rib.
2. Fasten each end of the ubar to the endcap with (2) 1/4-20 x 5/8" Tek screws.
3. Fasten both walls of the ubar to the rib using 1/4-20 x 5/8" Crimptite screws (approximately 18 Crimptite screws per 18' ubar).

